

Water heater/heater bypass valves




Valves are located under access panel beneath drivers-side bed. Valves shown in heater mode. To bypass heater turn both valves one quarter turn.

Hot water/heater pressure relief valve



Turn yellow handle 90° to drain water heater/heater unit

Fresh water valve system



Valves are located behind side panel under the bed. Valve 1 – selects potable water source. Shown in on-board tank position. Turn valve clockwise one quarter turn to select city water.

Valve 2 – TBD

NOTE: When using city water DO NOT run water pump